

Standard ECMA-403

1st Edition / June 2013

NFCIP-2 Test Methods

andam






COPYRIGHT PROTECTED DOCUMENT



Contents		Page
1	Scope	1
2	Conformance	1
3	Normative references	1
4	Acronyms	1
5	Test environment and apparatus	2
6	Tests	2
6.1	Test External RF Field detection	2
6.2	Test Mode selection and switching	
6.2.1	Test PICC mode	2
6.2.2	Test NFC mode, Target and Initiator	3
6.2.3	Test PCD mode	3
6.2.4	Test VCD mode	



Introduction



This Ecma Standard has been adopted by the General Assembly of June 2013.



"COPYRIGHT NOTICE

© 2013 Ecma International

This document may be copied, published and distributed to others, and certain derivative works of it may be prepared, copied, published, and distributed, in whole or in part, provided that the above copyright notice and this Copyright License and Disclaimer are included on all such copies and derivative works. The only derivative works that are permissible under this Copyright License and Disclaimer are:

- (i) works which incorporate all or portion of this document for the purpose of providing commentary or explanation (such as an annotated version of the document),
- (ii) works which incorporate all or portion of this document for the purpose of incorporating features that provide accessibility,
- (iii) translations of this document into languages other than English and into different formats and
- (iv) works by making use of this specification in standard conformant products by implementing (e.g. by copy and paste wholly or partly) the functionality therein.

However, the content of this document itself may not be modified in any way, including by removing the copyright notice or references to Ecma International, except as required to translate it into languages other than English or into a different format.

The official version of an Ecma International document is the English language version on the Ecma International website. In the event of discrepancies between a translated version and the official version, the official version shall govern.

The limited permissions granted above are perpetual and will not be revoked by Ecma International or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and ECMA INTERNATIONAL DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY OWNERSHIP RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE."

© Ecma International 2013 iii



iV © Ecma International 2013



NFCIP-2 Test Methods

1 Scope

This Standard specifies requirements to verify NFCIP-2 mode selection and initial communication in the selected modes. The Test Management Service Data Units and the interface over which they are exchanged are out of scope.

2 Conformance

Conforming implementations pass the tests in Clause 6 using the test environment and apparatus as specified in Clause 5.

3 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ECMA-340 NFCIP-1 – Near Field Communication Interface and Protocol -1 (ISO/IEC 18092)

ECMA-352 NFCIP-2 – Near Field Communication Interface and Protocol -2 (ISO/IEC 21481)

ECMA-356 NFCIP-1 - RF Interface Test Methods (ISO/IEC 22536)

ECMA-362 NFCIP-1 - Protocol Test Methods (ISO/IEC 23917)

ISO/IEC 9646 Information Technology – Open systems Interconnection – Conformance Testing methodology and framework

ISO/IEC 14443-3 Identification cards – Contactless integrated circuit cards – Proximity cards – Part 3: Initialization and anticollision

ISO/IEC 10373-6 Identification cards – Test methods – Part 6: Proximity cards

ISO/IEC 10373-7 Identification cards - Test methods - Part 7: Vicinity cards

4 Acronyms

IUT Implementation Under Test

LT Lower Tester

TB-PDU Transmission Block – Protocol Data Unit

TM-SDU Test Management – Service Data Unit

UT Upper Tester

© Ecma International 2013



5 Test environment and apparatus

The concepts and abstract model of ISO/IEC 9646 are used to verify the operation of an IUT compliant to ECMA-352.

NFCIP-2 test apparatus consists of an Upper Tester (UT) and a Lower Tester (LT) as illustrated in Figure 1.

To communicate with the IUT, e.g. to select modes on the IUT, the UT and IUT exchange TM-SDUs. The SDU definition and the interface between UT and IUT are out of scope of this Standard.

The NFCIP-2 test apparatus implements the specified modes at its LT interface according to the requirements of the test scenarios specified in Clause 6.




Figure 1 — test configuration

6 Tests

6.1 Test External RF Field detection

To verify that the IUT does not switch on its RF field, configure the LT as test circuit and perform the test in 8.1 of ECMA-352 while using the term NFCIP-2 device instead of NFCIP-1 device.

6.2 Test Mode selection and switching

6.2.1 Test PICC mode

- 1. Select PICC mode on the IUT and place it into the operating volume of the LT
- 2. Select PCD mode on the LT, and let the LT send REQA of ISO/IEC 14443-3,

© Ecma International 2013



- 2.1 If the IUT answers with ATQA of ISO/IEC 14443-3 within 1 ms and passes the PICC tests specified in ISO/IEC 10373-6, it passes the test, otherwise
- 2.2 Let the LT send REQB of ISO/IEC 14443-3: if the IUT answers with ATQB of ISO/IEC 14443-3 within 1 ms and passes the PICC tests specified in ISO/IEC 10373-6, it passes the test otherwise it fails the test.

6.2.2 Test NFC mode, Target and Initiator

- 1. For NFC, VCD and PCD mode selected on the IUT, place it in the operating volume of the LT and let the LT switch its RF field off for at least 5,1 ms, and select Initiator for Active communication mode, on either fc/128, fc/64 or fc/32 on the LT, and let the LT send ATR_REQ of ECMA-340 (see 8.5.1 of ECMA-362).
- 2. To test step 3 of Clause 7 of ECMA-352, verify that the IUT responds with ATR_RES of ECMA-340 for all three selected modes.
- 3. The LT shall switch off its RF field and select NFC mode, Passive communication mode, as a Target on the LT.
- 4. Select NFC mode on the IUT and verify that the IUT executes one of the Initiator protocols for *fc*/128, *fc*/64 or *fc*/32 of ECMA-340 as selected (see 9 of ECMA-362).

6.2.3 Test PCD mode

Use ISO/IEC 10373-6 to verify that the IUT operates in PCD mode with the LT as PICC mode emulator.

6.2.4 Test VCD mode

Use ISO/IEC 10373-7 to verify that the IUT operates in VCD mode with the LT as VICC mode emulator.

© Ecma International 2013

